
CLEAN
POT WASH SECTION
DISHWASHING UNIT
SINK UNIT
DIRTIES
BINS BEATH
HIG LEVEL SHELVING
PB-300
BASIN
PB-07.02
WC
P-06
FU-305
FURNITURE
FU-305
FURNITURE
LIGHTING
LI-36
PB-300
BASIN
FU-311
FURNITURE
FU-311
FURNITURE
FU-311
FURNITURE
FU-311
FURNITURE
FU-313
FURNITURE
FU-311
FURNITURE
FU-311
FURNITURE
FU-313
FURNITURE
FU-311
FURNITURE
FU-301
FURNITURE
FU-303
FURNITURE
FU-304
FURNITURE
FU-302
FURNITURE
FU-316.04
FURNITURE
LIGHTING
LI-38
FU-310
FURNITURE
FU-314
FURNITURE
FU-312
FURNITURE
FU-316.03
FURNITURE
FU-316.02
FURNITURE
FU-315
FURNITURE
FU-316.01
FURNITURE
FU-316.05
FURNITURE
J-308
JOINERY
FU-317
FURNITURE
FU-316
FURNITURE
J-304
JOINERY
FU-318
FURNITURE
FU-321
FURNITURE
FU-319
FURNITURE